


PW3100 Webcam Turn-off auto focus SOP



1.) Invoke "Camera" Apps under Windows 10 search bar




2.) Select Camera instance to "PW3100" by click **Change Camera** button



3.) Click "Setting" icon and make sure "Pro. menu" toggle button has been enabled.



4.) "Auto/Manual Focus" button appears once the Pro. mode menu enabled.



5.) Adjust camera focus by scrolling up/down to get clear image.

